

GoDogGo™

Canine Activity

Congratulations on choosing the original GoDogGo™ Canine Activity Sport. This product has been designed to provide hours of healthy exercise and enjoyment for you to share with your pet.

PLEASE be sure to read the following operating, training and care information prior to using your GoDogGo™ Canine Activity Sport.

SET UP AND OPERATION

GoDogGo™ may be powered either by battery or AC operation.

install 6 size "D" batteries in compartment located on the underside of the unit and/or connect the AC adapter to the control panel found at back of unit and then plug into electrical outlet.

WARNING: DO NOT USE AC ADAPTER in wet weather conditions or on wet grass, in this case please rely on battery source **ONLY**.

PLEASE keep your pet away from the ball kicker and out of the launching pattern as well as any children, spectators and/or operator to avoid direct contact or injury from ball. REMEMBER TO STAY CLEAR OF THE DIRECT LAUNCH PATTERN!

Once you have determined where you are going to exercise your pet with GoDogGo™ adjust the unit to the appropriate launch and intermittent time sequence. The following conditions will determine how you preset the unit:


•Size of yard or exercise space. •Physical condition of your pet.

•Weather conditions:

**DO NOT USE IN EXTREME HEAT OR COLD!
ALWAYS CONSIDER YOUR PET'S HEALTH.**

First determine the distance you wish to launch the ball, (from 15 to 30 feet) then make that adjustment from the bottom of the unit. **ONLY MAKE THIS ADJUSTMENT WHILE THE UNIT IS TURNED OFF AND UNPLUGGED!**

Take hold of the ring which positions itself between one of 4 distance slots. The slot located nearest the front of the unit, (towards the GoDogGo logos on the front) is the 15 foot slot. The next slot is 20' with 5' increases to max. 30'.



This unit is designed to launch a tennis ball from 15' to 30' intermittently from 7 seconds or 15 seconds. The settings should be adjusted accordingly: a long launch distance will require a greater amount of time in order for your pet to return ball to the unit. Launch distance may be affected by the condition of the balls used, i.e. WET or OLD tennis balls.

Load the ball bucket of GoDogGo™ with the tennis balls included. The maximum number of balls recommended for use at any one time is 15